




























|   |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |  |
|---|---|---|---|---|---|---|---|---|---|---|--|---|---|---|---|---|---|---|
| max. Höhe: 120 cm<br><br>max. 250 cm   |   | ●   | ●   | ●   | ●   | ●   | ●   | ●   | ●   | ●   | ●  | ●   | ●   | ●   | ●   | ●   | ●   | ●   |
| max. Höhe: 150 cm<br><br>max. 250 cm   | ●   | ●   | ●   | ●   | ●   |   |   | ●   | ●   | ●   | ●  | ●   | ●   | ●   | ●   | ●   | ●   | ●   |
| max. Höhe: 120 cm<br><br>max. 180 cm  | ●   | ●   | ●   |   | ●   |   |   | ●   | ●   | ●   | ●  | ●   | ●   | ●   | ●   |   | ●   | ●   |
| max. Höhe: 150 cm<br><br>max. 180 cm | ●   | ●   | ●   |   |   |   |   | ●   | ●   | ●   | ●  | ●   | ●   | ●   | ●   |   | ●   | ●   |
| max. Höhe: 180 cm<br><br>max. 180 cm | ●   |   |   |   |   |   |   |   |   |   |  |   |   |   |   |   |   |   |
| max. Höhe: 180 cm<br><br>max. 250 cm | ●   | ●   | ●   |   |   |   |   |   |   |   |  |   |   |   |   |   |   |   |
| max. Höhe: 200 cm<br><br>max. 250 cm | ●   | ●   | ●   |   |   |   |   |   |   |   |  |   |   |   |   |   |   |   |
| max. Höhe: 260 cm<br><br>max. 250 cm | ●   |   |   |   |   |   |   |   |   |   |  |   |   |   |   |   |   |   |
| max. Höhe: 260 cm<br><br>max. 250 cm | ●   |   |   |   |   |   |   |   |   |   |  |   |   |   |   |   |   |   |

# RICHTWERTTABELLE

Beim Bauen von Holzkonstruktionen spielt die Statik eine wichtige Rolle. Sie wird beeinflusst durch Holzstärken und -arten, Schrauben, Pfostenabstände und Bauweise.